


## Como verificar a compilação da placa de Gerencia da OLT Fiberhome.


**Pré-requisitos:** Para verificar compilação das placas é necessário que tenha acesso a **OLT** via telnet ou console.

- Verificando a Compilação da placa de gerencia (**HSWA/HSUB/HSUA**).

### Passo 1 – acessando a OLT via telnet/console:

Se o acesso for através de telnet, basta colocar o tipo de conexão “**Telnet**” e informar o IP que está na OLT.





Login: **GEPON**  
Password: **GEPON**




User: **EN**  
Password: **GEPON**


## Passo 2 – acessando a placa de gerencia:

No diretório “admin#” digitar: **lll** (3 vezes a letra L)

Dentro do **modo debug**, digitar o comando: **show debugv**



Verificando o ano de compilação da placa de gerencia.



```
192.168.200.250 - PuTTY
Master
User> EN
Password: *****
Admin# 111
Admin(DEBUG_H)> show deb
Admin(DEBUG_H)> show debugv

BOOT version: BSP version : 3.1/0 HSWA
CreationDate: Mar 20 2010, 14:33:54

Fiberh
ome Telecommunication Technologies Co., Ltd.

Main      version is 30.7.0 (AN5516-01), Compiled Time:Mar 24 2016 15:26:38
IGMPProxy version is 30.7.3, Compiled Time:Mar 24 2016 15:23:23
Snmp      version is 30.7.1, Compiled Time:Mar 24 2016 15:25:17
Bridge    version is 30.7.14, Compiled Time:Mar 24 2016 15:21:03
CLI       version is 30.7.14, Compiled Time:Mar 24 2016 15:21:16
QoS       version is 30.7.1, Compiled Time:Mar 24 2016 15:24:46
```